


User Manual


A. Features

- 13 Digits LCD Display, Display Hour, Minute, Second, Month, Day, Year and Week
- Automatic Calendar (2000 – 2099)
- Dual Time
- 12 / 24H format selectable, Auto Calendar
- Daily Alarm ,Chime hourly and SNZ
- 1/100 second to 23 hour 59.99 second Chronograph with split functions,12 groups of LAP segment timing
- Countdown function
- EL backlight
- Touch-tone




B. Operational Manual

1. At any mode, press A key EL backlight for 3s.
2. Press B to change the display mode
3. In real time mode press D key to switch 12 hours or 24 hours display.
4. Real Time and date




- Time Setting
 - a) Press and hold C key for 2s to time setting mode and „Second“ flashing, Press B key to select item as following sequence:
 - b) Press D key while the seconds are in the range of 30 to 59, resetting them to 00 and adding 1 to the minutes. While the seconds are in the range of 00 to 29, the minutes won't be changed.
 - c) Press D key to adjust the value increment, hold down D key to quickly adjust.
 - d) Press C key to return to Real Time Mode.
 - e) In setting mode. 1 minute No key operation automatically exit setting, return to real time display mode.




5. Dual Time Mode

- In the real time mode, Press B key 3 times to enter Dual Time Mode.
- Press and hold C key for 2s to select „Hour“, setting, Press B key to select „Minute“, setting.
- Press D key to adjust the value increment, hold down D key to quickly adjust.
- Press C key again to finish setting and return to Dual Time displaying mode.
- In setting mode. 1 minute No key operation automatically exit setting, return to Dual Time displaying mode.
- The second of Dual Time is the same as real time.




6. Daily Alarm

- Turn On / Off Alarm, Chime and Snooze
- a) In Alarm mode, press D and then press C key to turn on/off Alarm (A),
- b) In Alarm Mode, press C to turn on/off hourly chime (B) and snooze (C),



7. Alarm Mode

- In alarm mode, press and hold C key for 2 seconds to enter the alarm time setting state, then press B key to select the setting items as follows:
- Press D key to adjust the value increment, hold down D key to quickly adjust.
- Press C key to return to Alarm Mode.
- In setting mode. No any key operation then will back to alarm display mode automatically after 1 minute.



Remarks:

- When you need a daily alarm, do not enter a number at the bottom of the screen. Please set it to „- - -“.
- When you need a specify month alarm, you need to enter the number „12- -“ at the bottom of the screen.
- When you need a specify day alarm, you need to enter the number „- - -30“ on the bottom of the screen.
- When you need a specify date alarm, you need to enter the number, such as „12-30“ at the bottom of the screen.
- When Alarm is ON, the BB-BB - ring sounds for 10 seconds, the alarm when the screen symbol „ „ flashing, press any key to stop.

Snooze function:


- In the Snooze function, The symbol „SNZ“ is still flashing on the screen when the alarm stopped, snooze rings every 5minutes,total ring 6 times.
- When the snooze is ringing, press any key is to stop all the after snooze function.

8. Chronograph mode

- The measurement range of chronograph is 23 hours 59 minutes 59.99 seconds, when reach the maximum, the chronograph re-count from „0“
- Chronograph LAP segment timing can remember 12 groups.

When running the Chronograph:

- Press D key to Start/Stop running; When stop, press C key to zero.
- When running, press C key to split counting, Press C key again to next LAP split counting.
- In the split counting, press D key to stop counting, press C key to view the memory mode, press C key again to continue to view the next memory.
- When exit split count, hold on C key for 2 seconds to zero.
- When running, press B key to return to Real Time mode, and it runs at back.




9. Countdown mode


- The display range of the timer is 1 minute to 23hour 59minute.

In the countdown mode

- Press and hold C key for 2s to time setting mode and „Seconds“ flashes. Press B key to select „Hour“, then Press B key „Minute“ setting.



- Press D key to adjust the value increment, hold down D key to quickly adjust.
- Press C key to confirm, press B key return to the real time mode.
- In setting mode. No any key operation then will back to countdown mode automatically after 1 minute.
- Press D key to Start/Stop counting. Press C key for 2s to starting value when stop counting. Press C key for 2s again back to the setting mode.



- When the countdown stop to zero, the BB-BB - ring sounds for 15 seconds, press any key to stop the ring, when the ring stop, the countdown time will automatically return to the initial setting time.